

FIAT BSI WIRING DIAGRAMS 2

#FIAT BSI DELPHI 70F3379+93C86

#FIAT BSI DELPHI 70F3237+93C86

#FIAT BSI DELPHI 70F3633

#FIAT BSI MAGNETI MARELLI 3K91D

#FIAT BSI MAGNETI MARELLI 1K79X

#FIAT BSI MAGNETI MARELLI 70F3237+95160




#FIAT BSI MAGNETI MARELLI 70F3378+95160

#FIAT BSI MAGNETI MARELLI 70F3633+95320

#FIAT BSI SIEMENS/CONTINENTAL 9S12DG128


#FIAT BSI MAGNETI MARELLI MB91465P+95640

FIAT BSI DELPHI 70F3633






+12V	GND	CANH	CANL
A, C11	C10	B59	B60

Connecting directly to ioterminal




FIAT BSI DELPHI 70F3379+93C86








+12V	GND	CANH	CANL
A, C11	C10	B59	B60

Connecting directly to ioterminal




FIAT BSI DELPHI 70F3237+93C86




+12V	GND	CANH	CANL
A,D32	C10	D21	D22

Connecting directly to ioterminal




FIAT BSI MAGNETI MARELLI 70F3237+95160
FIAT BSI MAGNETI MARELLI 70F3378+95160
FIAT BSI MAGNETI MARELLI 3K91D
FIAT BSI MAGNETI MARELLI 1K79X




A9 - IGNITION

Connecting directly to ioterminal




FIAT BSI SIEMENS/CONTINENTAL 9S12DG128







A1 - IGNITION

Connecting directly to ioterminal




FIAT BSI MAGNETI MARELLI 70F3633+95320






A2 - IGNITION

+12V	GND	CANH	CANL
A2, C	A11	B24	B9


Connecting directly to ioterminal



FIAT BSI MAGNETI MARELLI MB91465P+95640 BACK



A2 - IGNITION



+12V	GND	CANH	CANL
A2, C	A11	B24	B9

Connecting directly to ioterminal

